



## 2008 Complete Air Suspension Application List



Semi Air Kits



Coil Rite Kits



LSV Kits



Full Air Kits

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS	
							SINGLE	DUAL
<b>Acura SUV's</b>								
MDX	01-08					4138	6017	2236 2436
<b>Audi</b>								
A6	98-07					4105	6013	2236 2436
<b>Buick Cars</b>								
Centurion	71-73					4116	6010	2236 2436
Century	82-96	Including station wagons / FWD				4103	6014	2236 2436
Century	73-87	Including station wagons / RWD				4114	6008	2236 2436
Electra	85-96	No station wagons				4107	6021	2236 2436
Grand Sport	73-87					4114	6008	2236 2436
LeSabre	86-99	Including station wagons / FWD				4107	6021	2236 2436
LeSabre	65-84	No station wagons				4116	6010	2236 2436
LeSabre	00-05	No station wagons / FWD				4105	6013	2236 2436
LeSabre	85	Rear Wheel Drive				4116	6010	2236 2436
LeSabre Estate Wagon	77-90					4116	6010	2236 2436
Luxus	73-87	Including station wagons / RWD				4114	6008	2236 2436
Park Avenue	97-05					4105	6013	2236 2436
Park Avenue	85-96	No station wagons				4107	6021	2236 2436
Regal	73-87	Including station wagons / RWD				4114	6008	2236 2436
Riviera	95-98					4105	6013	2236 2436
Riviera	79-85					4106	6015	2236 2436
Roadmaster, Roadmaster Estate Wagon	91-96					4116	6010	2236 2436
Skyhawk	82-89	Including station wagons				4104	6012	2236 2436
Skylark	85-96					4104	6012	2236 2436
Skylark	80-84					4103	6014	2236 2436
Somerset	85-87					4104	6012	2236 2436
Special, Deluxe, Grand Sport, Skylark	67-72	No station wagons				4113	6007	2236 2436
Wildcat	65-69					4116	6010	2236 2436
<b>Buick Van</b>								
Terraza	05-07					4155	6020	2236 2436
<b>Cadillac Cars</b>								
All Rear Drive Models	65-93					4116	6010	2236 2436
CTS, STS	06-08					4168	6027	2236 2436
Coupe Deville, Fleetwood, Sedan Deville, Touring Sedan (FWD)	85-93					4107	6021	2236 2436
El Dorado	79-85					4106	6015	2236 2436
Seville	80-85					4106	6015	2236 2436
<b>Cadillac SUVs</b>								
Escalade, EST, ESV (4x2, 4x4)	00-08	4x2 / 4x4				4108	6003	2236 2436
Escalade (4x2, 4x4) (4door only)	99-00	4x2 / 4x4				2101	6781	2236 2436
<b>Chevrolet Cars</b>								
Beretta, Corsica	88-96					4104	6012	2236 2436
Camaro, Z-28, IROC-Z	82-02					4103	6014	2236 2436
Caprice	71-96	No station Wagons				4116	6010	2236 2436
Caprice	77-96	Station Wagon				4116	6010	2236 2436
Cavalier	82-94	Including station wagons				4104	6012	2236 2436
Celebrity	82-90	Including station wagons				4103	6014	2236 2436
Chevelle	73-83	Including station wagons				4114	6008	2236 2436
Chevelle	67-72					4113	6007	2236 2436
Cosica	88-96					4104	6012	2236 2436
El Camino	67-87					4114	6008	2236 2436
Impala	71-96	No station Wagons				4116	6010	2236 2436

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS	
							SINGLE	DUAL
<b>Chevrolet Cars (Continued)</b>								
Impala	77-96	Station Wagon				4116	6010	2236 2436
Laguna	73-83	Including station wagons				4114	6008	2236 2436
Malibu	67-72					4113	6007	2236 2436
Malibu	73-83	Including station wagons				4114	6008	2236 2436
Monte Carlo SS	84-88	SS only				4113	6007	2236 2436
Monte Carlo	73-88	Not SS				4114	6008	2236 2436
Monte Carlo	67-72					4113	6007	2236 2436
<b>Chevrolet / GMC Vans / Class 'C' Motorhomes</b>								
Lumina APV	90-96					4110	6015	2236 2436
Astro, Safari	99-05	4x2 / 4x4				2361	6397	2236 2436
Astro, Safari	85-98	4x2 / 4x4 cargo van only, not passenger van, continuously loaded vehicles only				2029	0335	2236 2436
G-10, G-20, G-30, G-1500, G-2500, G-3500	70-95		4100	6000		0830	0335	2236 2436
G-1500, G-2500	03-08	6 lug nuts				2423	6868	2236 2436
G-1500, G-2501	96-02	6 lug nuts				2163+++	9001	2236 2436
G-2500	96-02	8 lug nuts / Over 8600 GVW				2185	9000	2097 2219
G-2500	03-07	8 lug nuts / Over 8600 GVW				2337	9000	2097 2219
G-3500	98-07	RV & commercial cutaway				2173	6959	2097 2219
Uplander	05-08					4155	6020	2097 2219
<b>Chevrolet / GMC SUVs</b>								
Avalanche 1500	02-08	4x2 / 4x4				4108	6003	2236 2436
S-10 Blazer	85-94	4x4 / compact utility				2022	0335	2236 2436
Blazer	73-91	full size / 4x2	4100	6000				2236 2436
Blazer	73-91	full size / 4x4	2119	6959				2236 2436
Denali XL 2500	00-08	4x2 / 4x4				2253	6781	2236 2436
Envoy	02-08	With rear coil springs (4x4, 4x2)				4106	6015	2236 2436
Equinox	05-06	4x2 / 4x4				4167	6027	2236 2436
Jimmy	73-91	4x2	4100	6000				2236 2436
Jimmy	73-91	4x4	2119	6762				2236 2436
S-15 Jimmy	85-94	4x4 / compact utility				2022	0335	2236 2436
Suburban 1500	00-08	4x2 / 4x4				4108	6003	2236 2436
Suburban 1500	92-99	4x2 / 4x4				2101	6781	2236 2436
Suburban 1500	73-91	4x2	4100	6000		2100	6781	2236 2436
Suburban 1500	73-91	4x4	2119	6959		2100	6781	2236 2436
Suburban 2500	00-08	4x2 / 4x4	1003	7210		2253	6781	2236 2436
Suburban 2500	92-99	4x2 / 4x4				2101	6781	2236 2436
Suburban 2500	73-91	4x2	4100	6000		2100	6781	2236 2436
Suburban 2500	73-91	4x4	2119	6959		2100	6781	2236 2436
Tahoe	00-08	4x2 / 4x4				4108	6003	2236 2436
Tahoe	95-99	4-door / 4x2 / 4x4				2101	6781	2236 2436
Trailblazer	02-08	4x2 / 4x4				4106	6015	2236 2436
Yukon 1500	00-08	4x2 / 4x4				4108	6003	2236 2436
Yukon 1500	95-99	4-door / 4x2 / 4x4				2101	6781	2236 2436
Yukon 1500	92-98	2-door				2173	6959	2236 2436
Yukon XL 2500	00-08	4x2 / 4x4	1003	7210		2253	6781	2236 2436
Yukon 2500	95-99	4-door only / 4x2 / 4x4				2101	6781	2236 2436
<b>Chevrolet / GMC Pickup Trucks</b>								
S-10 Crew Cab	04	(4x2 only)				2209	9001	2236 2436
S-10, Sonoma	82-03	(4x2 only) (not factory lowered ZQ8)				2209	9001	2236 2436
Colorado/Canyon	04-08	(4x2, 4x4) (not factory lowered ZQ8)				2384	6397	2236 2436
C & K-1500 Silverado, Sierra	07-08	(4x4 only)				2430	6397	2236 2436
C & K-1500, Silverado Classic, Sierra Classic	07	(4x2, 4x4)				2320 ++	9000	2236 2436
C & K-1500, Silverado, Sierra	99-06	(4x2, 4x4) (not HD)				2320 ++	9000	2236 2436
C-1500 HD Silverado, Sierra	05-06	(4x2, 4x4)	1003	7210		2190	6781	2236 2436
C-1500 HD Silverado, Sierra	01-03	(4x2, 4x4)	1003	7210		2190	6781	2236 2436
C & K-1500	88-98	(4x2, 4x4)				2025	6781	2236 2436
C & K-1500	88-98	(4x2 only)				2162	9002	2236 2436
C-1500 LOWERED	88-98	(4x2 only) (w/ C notch & axle flip)				2252 *	6762	2236 2436
C & R 10, 1500	73-87	(4x2 only)	4100	6000		2071 *	6781	2236 2436
K & V-10, 1500	73-87	(4x4 only)	2119	6762		2040 ***	0335	2236 2436
C-2500, Silverado, Sierra	99-05	(4x2, 4x4) (not HD)	1003	7210		2190	6781	2236 2436
C-2500 HD, Silverado, Sierra Classic	01-08	(4x2, 4x4)	1003	7210		2250	6781	2236 2436

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS	
							SINGLE	DUAL
<b>Chevrolet / GMC Pickup Trucks (Continued)</b>								
C & K-2500	99-00	(4x2, 4x4) (with rear drum brakes)				2025	6781	2236 2436
C & K-2500	88-98	(4x2, 4x4)				2025	6781	2236 2436
C & R-20	73-87	(4x2 only)	4100	6000	2071 *	6781	2236	2436
K & V-20, 2500	73-87	(4x4 only)	2119	6762	2040 ***	0335	2236	2436
C-3500 Classic	01-08	(4x2, 4x4)	1003	7210	2250	6781	2236	2436
C & K-3500	88-00	(4x2, 4x4)			2025	6781	2236	2436
C-3500 LOWERED (4x2 only) 3"/5" (no axle flips)	92-00	(4x2 only)			2263	6868	2236	2436
C & R-30, 3500	73-87	(4x2 only)			2071 *	6781	2236	2436
C-30	67-87	(4X2 only)	4100	6000	2071 *	6781	2236	2436
C & R-30, 3500	73-91	(4x2 only)			2099	0335	2236	2436
K & V-30, 3500,	73-87	(4x4 only)	2119	6762	2040 ***	0335	2236	2436
<b>Chevrolet / GMC Commercial Vehicles</b>								
C 2500 HD,C 3500 HD	01-08	(4x2, 4x4)	1003	7210	2249	6781	2097	2219
C-3500	88-00	(Type I ambulance chassis)			2065 ***	0335	2097	2219
C-4500, C-5500	02-08		2451	6401	2362 *	6781	2097	2219
C-Series 5, 6, 7	90-99		2053	0335			2097	2219
G-3500	98-09	(with dual rear wheels)			2173	6762	2097	2219
G-30, G-3500	70-95		4100	6000	0830	6859	2097	2219
W-3500	96-08		2440	6868			2097	2219
<b>Chevrolet / GMC Motorhomes Class 'C' Vans</b>								
G-3500	98-09	(with dual rear wheels)			2173	6762	2097	2219
G-30, G-3500	70-95		4100	6000	0830	6859	2097	2219
<b>Chevrolet / GMC Step Van, Class 'A' Motorhomes</b>								
GP-30 HD	93-96	(cutaway) (10,500 to 12,300 GVWR)	4100	6001	2080	0335	2097	2219
GP-30 HD	93-96	(cutaway) (14,500 GVWR)	4100	6002	2085	0335	2097	2219
P-20, P-30	86-92	(step van) (with square axle)			2121	7325	2097	2219
P-30 (10,500 to 12,800 GVWR)	93-96	(with jounce bumpers mounted at bottom of frame rails)	4100	6000	2080	0335	2097	2219
P-30 (14,500 to 16,000 GVWR)	93-99		4100	6001	2147 *	6781	2097	2219
P-30 (14,500 to 17,000 GVWR)	93-99	(with jounce bumper mounted above leaf springs)	4100	6002	2085	0335	2097	2219
P-30	63-92	(with jounce bumpers mounted at bottom of frame rails)	4100	6003	2080	0335	2097	2219
<b>Chrysler Cars</b>								
Imperial	90-94				4105	6013	2236	2436
Le Baron, GTS, TC By Maserati	82-95				4105	6013	2236	2436
New Yorker	84-89				4105	6013	2236	2436
PT Cruiser	01-08				4139	6015	2236	2436
Town and Country Station Wagon	84-89				4105	6013	2236	2436
<b>Chrysler Van</b>								
Town and Country	08				4169	6013	2236	2436
<b>Chrysler SUVs</b>								
Aspen	07-08	(4x2, 4x4)			4152	6009	2236	2436
<b>Citroen Light Commercial Vehicles</b>								
Berlingo C4	2008	Full Air Kit-Electronic Height Control-With Lowering			3168	9000	---	---
DISPATCH - JUMPY	96-06	For Use with Original Coil			4143	6016	2236	2436
DISPATCH - G9	07-08	For Use with Original Coil			4264	6016	2236	2436
DISPATCH - JUMPY	96-06	Full Air Kit-Rear Axle Kit only c/w shock absorbers			3150	9000	---	---
DISPATCH - JUMPY	96-06	Full Air Kit-Electronic Height Control-With Lowering			3260	9000	---	---
DISPATCH - G9	07-08	Full Air Kit-Electronic Height Control-With Lowering			3496	9931	---	---
C25 - Euro Chassis 280/290	88-93	For All Applications			2112	6781	2236	2436
C25 - Euro Chassis 280/290	88-93	LSV Kit For Non-ABS Vehicles			3003	3000	2236	2436
C25 - Euro Chassis 280/290	88-93	LSV Linkage For Non-ABS Vehicles (Motorhomes)			3149	Link	2236	2436
JUMPER / RELAY - Euro Chassis X230	94-01	Commercial Vehicle Application			2110	6781	2236	2436
JUMPER / RELAY - Euro Chassis X230	94-01	LSV Kit For Non-ABS Vehicles			3003	3000	2236	2436
JUMPER / RELAY - Euro Chassis X230	94-01	LSV Linkage For Non-ABS Vehicles (Motorhomes)			3149	Link	2236	2436
JUMPER / RELAY - Euro Chassis X244	02-06	Commercial Vehicle Application			2110	6781	2236	2436
JUMPER / RELAY - Euro Chassis X244	02-06	LSV Kit For Non-ABS Vehicles			3178	Cylinder	2236	2436
JUMPER / RELAY X250	06-08	All Applications			2428	6781	2236	2436
JUMPER / RELAY X250	06-08	Larger Airsprings For Extra Volume and Comfort			2429	7339	2236	2436
JUMPER / RELAY X250	06-08	Full Air Improvement Comfort Kit			3202	9934	---	---
<b>Daihatsu</b>								
Rocky	00-07	For Use with Original Coil			4580	4580	2236	2436
<b>Dodge Cars</b>								
400, 600, Lancer, Daytona	82-94				4105	6013	2236	2436
Aries	81-89				4105	6013	2236	2436
Dynasty, Spirit	90-94				4105	6013	2236	2436
Shadow	87-94				4105	6013	2236	2436

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS	
							SINGLE	DUAL
<b>Dodge Vans</b>								
Caravan, Grand Caravan	08					4169	6013	2097 2219
Sprinter 2500	07-08					2447	6397	2097 2219
Sprinter 3500	07-08					2455	6781	2097 2219
Sprinter 2500	03-06					2312++	9002	2097 2219
Sprinter 3500	03-06					2425	6781	2097 2219
B100, B150, B200, B250, B300, B350, 1500, 2500, 3500, MB300, MB400	77-03					2109	6781	2097 2219
B100, B200, B300	71-76					0830	6859	2236 2178
<b>Dodge SUVs</b>								
Nitro	07-08	(4x2, 4x4)				4146	6781	2236 2436
Durango	04-08	(4x2, 4x4)				4152	6781	2236 2436
Durango	94-02	(4x2, 4x4) (not SXT)				2222	6781	2236 2436
<b>Dodge Pickup Trucks</b>								
Ram 50, Plymouth Arrow	80-93	4x2				1130 **	0335	2236 2436
Dakota Club Cab	05-08	(4x2, 4x4)				2378 +++	9000	2236 2436
Dakota Quad Cab (4x2, 4x4)	05-08	(4x2, 4x4)				2379 +++	9000	2236 2436
Dakota Standard & Crew Cab	97-02	(4x2 only)				2169 +++	9000	2236 2436
Dakota	97-03	(4x4 only) (not crew cab)				2162 +++	9002	2236 2436
Dakota Crew Cab	00-03	(4x4 only)				2217 +++	9000	2097 2436
Dakota	87-96	(4x2 only)				2023	0335	2236 2436
Ram 1500	02-08	(4x2, 4x4)				2286	6781	2236 2436
Ram 1500 Mega Cab	06-08	(4x2, 4x4)				2299	6401	2236 2436
Ram 1500	94-01	(4x2 only)				2071 *	6781	2236 2436
Ram 1500	94-01	(4x2 only)				2162 +++	9002	2236 2436
Ram 1500	94-01	(4x4 only)				2071 *	6781	2236 2436
Ram 1500	94-01	LIFTED 4" WITH SPRINGS (4x2, 4X4)				2264 *	6781	2236 2436
D & W 100, 150, Ram 1500	69-93	(4x2, 4x4)				2071 *	6781	2097 2219
D & W 100, 150, Ram 1500 LIFTED	69-93	(4X2, 4X4)				2264 *	6781	2097 2219
Ram 2500	03-08	(4x2, 4x4)				2299	6401	2097 2168
Ram 2500	94-02	(4x2 only)				2071 *	6781	2097 2219
Ram 2500	94-02	(4x4 only)				2071 *	6781	2097 2219
D & W 200, 250, Ram 2500	69-93	(4x2, 4x4)				2071 *	6781	2097 2219
Ram 2500	94-98	(4x2, 4x4) (with contact overload springs)				2220	6781	2097 2219
D & W 200, 250, Ram 2500	69-02	LIFTED 4" WITH SPRINGS (4x2, 4x4)				2264 *	6781	2097 2219
Ram 3500	03-08	(4x2, 4x4)				2299	6401	2097 2219
Ram 3500	94-02	(4x2 only)				2071 *	6781	2097 2219
Ram 3500 (4x4 only)	94-02	(4x4 only)				2071 *	6781	2097 2219
D & W 300, 350, Ram 3500	69-93	(4x2)(4x4)				2071 *	6781	2097 2219
D & W 300, 350, Ram 3500	69-02	LIFTED 4" WITH SPRINGS (4X2, 4x4)				2264 *	6781	2097 2219
<b>Dodge Commercial Vehicles</b>								
Ram 2500, 3500	04-08	(4x2, 4x4) (not dually)				2299	6401	2097 2219
Ram 3500	06-08	(4x4 only) (dually only)				2299	6401	2097 2219
Ram 3500 HD	07-08	(4x2, 4x4) (Cab & Chassis)				2071 *	6781	2097 2219
D3500, W3500	94-02	(4x2, 4x4) (Cab & Chassis)				2220	6781	2097 2219
Ram 4500, Ram 5500	04-08	(4x2, 4x4) (Requires 2" Clearance Above Frame)				2404***	7325	2097 2219
Sprinter 2500	03-06	(Cab & Chassis)				2312++	9002	2097 2219
Sprinter 3500	02-06	(Van & Cab & Chassis)				2425	6781	2097 2219
Sprinter 3500	02-06	(Cab & Chassis)				2382	6397	2097 2219
<b>Dodge Motorhomes Class "C" Vans</b>								
Sprinter 2500	07-08	(Cab & Chassis)				2447	6397	2097 2219
Sprinter 3500	07-08	(Cab & Chassis)				2455	6781	2097 2219
Sprinter 2500	03-06	(Van and Cab & Chassis)				2312 +++	9002	2097 2219
Sprinter 3500	03-06	(Van and Cab & Chassis)				2425	6781	2097 2219
Sprinter 3500	03-06	(Cab & Chassis)				2382	6781	2097 2219
B100, B150, B200, B250, B300, B350, 1500, 2500, 3500, MB300, MB400	77-03					2109	6781	2097 2219
B100, B200, B300	71-76					0830	6859	2097 2219
<b>Dodge Motorhomes Class "A"</b>								
M300, M400, M500, M600	73-82		1170	6859	1156	1132	2097	2219
M300, M400, M500, M600	68-72		1170	6859			2097	2219

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS		
							SINGLE	DUAL	
<b>Fiat</b>									
Scudo	96-06	For Use with Original Coil				4143	6016	2236	2436
Scudo-G9	07-08	For Use with Original Coil				4264	6016	2236	2436
Scudo	96-06	Full Air Kit-Rear Axle Kit only c/w shock absorbers				3150	9000	---	---
Scudo	96-06	Full Air Kit-Electronic Height Control-With Lowering				3260	9000	---	---
Scudo G-9	07-08	Full Air Kit-Electronic Height Control-With Lowering				3496	9931	---	---
Doblo Cargo	03-08	No Anti Roll Bar				2114	6781	2236	2436
Doblo Panorama	03-08	With Anti Roll Bar (Passanger Vehicle Only)				2117	7073	2236	2436
Ducato - Euro Chassis 280/290	88-93	For All Applications				2112	6781	2236	2436
Ducato - Euro Chassis 280/290	88-93	LSV Kit For Non-ABS Vehicles				3003	3000	2236	2436
Ducato - Euro Chassis 280/290	88-93	LSV Linkage For Non-ABS Vehicles (Motorhomes)				3149	Link	2236	2436
Ducato - Euro Chassis X230	94-01	Commercial Vehicle Application				2110	6781	2236	2436
Ducato - Euro Chassis X230	94-01	Motorhome Vehicle Application				2207	6781	2236	2436
Ducato - Euro Chassis X230	94-01	LSV Kit For Non-ABS Vehicles				3003	3000	2236	2436
Ducato - Euro Chassis X230	94-01	LSV Linkage For Non-ABS Vehicles (Motorhomes)				3149	Link	2236	2436
Ducato - Euro Chassis X244	02-06	Commercial Vehicle Application				2110	6781	2236	2436
Ducato - Euro Chassis X244	02-06	Motorhome Vehicle Application				2207	6781	2236	2436
Ducato - Euro Chassis X244	02-06	LSV Kit For Non-ABS Vehicles				3178	Cylinder	2236	2436
Ducato X250	06-08	All Applications				2428	6781	2236	2436
Ducato X250	06-08	Larger Airsprings For Extra Volume and Comfort				2429	7339	2236	2436
Ducato X250	06-08	Full Air Improvement Comfort Kit				3202	9934	---	---
<b>Ford Cars</b>									
Country Squire	83-97					4108	6003	2236	2436
Crown Victoria	98-07	With rear coil springs				4107	6021	2236	2436
Crown Victoria	83-97					4108	6003	2236	2436
Fusion	06-08					4169	6013	2236	2436
LTD	83-86					4103	6014	2236	2436
Mustang	79-03					4103	6014	2236	2436
Taurus Station Wagon	99-06					4141	6005	2236	2436
Taurus Station Wagon	86-98					4105	6013	2236	2436
Thunderbird	92-97					4105	6013	2236	2436
Thunderbird	89-91					4104	6012	2236	2436
Thunderbird	80-88					4106	6015	2236	2436
<b>Ford Vans / Class 'C' Motorhomes</b>									
Freestar	04-07					4151	6016	2236	2436
Windstar	98-03					4106	6015	2236	2436
E-150	75-08		4101	6002	2171	7076	2236	2436	
E-100, E-150	75-91	May require tailpipe modification	4101	6002	2032	6859	2236	2436	
E-250	92-08		4101	6002	2165	9002	2236	2436	
E-250	75-91	May require tailpipe modification	4101	6002	2032	0335	2236	2436	
E-350	92-08	With single rear wheels	4101	6002	2181	9000	2097	2168	
E-350	75-91	May require tailpipe modification	4101	6002	2032	6859	2097	2168	
<b>Ford CUVs</b>									
Edge	07-08					4171	6020	2236	2436
<b>Ford SUVs</b>									
Bronco	80-90	4x2, 4x4	4102	6011			2236	2436	
Bronco	90-96	Full size / 4x4	4102	6011	2071*	6781	2236	2436	
Bronco	90-96	Full size / 4x4 / +4' Lift			2264*	6781	2236	2436	
Expedition	97-02	With rear coil springs / 4x2 / 4x4			4134	6022	2236	2436	
Excursion	00-06	4x2			2255	6781	2236	2436	
Excursion	00-06	4x4			2251	6781	2236	2436	
<b>Ford Pickup Trucks</b>									
Ranger <EUROPE>	00-08	4x4 For Vehicles Fitted With ABS				3454	6781	2236	2436
Ranger <USA>	83-08	Not for use with composite leaf (4x2)(4x4)				2172++	9001	2236	2436
F-100	68-79	4x2 / 4x4	4102	6011	2071*	6781	2236	2436	
F-150 Heritage	04-07	4x2 / 4x4 (Old Body Style)				2350#	6781	2097	2219
F-150	04	4x2 / 4x4				2320++	6397	2097	2219
F-150	97-03	4x2 / 4x4				2320++	9000	2236	2436
F-150	68-96	4x2 / 4x4	4102	6011	2071*	9000	2236	2436	
F-150	68-96	4x2 / 4x4				2264*	6781	2236	2436
F-250	97-03	Under 8500 GVWR / 4x2,4x4				2320++	6781	2236	2436
F-250	69-96	Under 8500 GVWR / 4x2	4101	6002	2071*	9000	2236	2436	
F-250	84-08	Over 8500 GVWR / 4x2	4101	6002	2071*	6781	2097	2219	
F-250	69-83	Over 8500 GVWR / 4x2				2320++	6781	2097	2219

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS	
							SINGLE	DUAL
<b>Ford Pickup Trucks (Continued)</b>								
F-250	05-08	Over 8500 GVWR / 4x4	4160	6025	2071*	9000	2236	2436
F-250	84-04	Over 8500 GVWR / 4x4	2223	6762	2071*	6781	2097	2219
F-250	69-03	Over 8500 GVWR / 4x4			2071*	6781	2097	2219
F-250	08	Over 8500 GVWR / 4x2 only with in bed hitch	4101	6002	2450	6401	2097	2219
F-250	05-07	Over 8500 GVWR / 4x2 with in bed hitch	4101	6002	2398	6781	2097	2219
F-250	08	Over 8500 GVWR / 4x4 only with in bed hitch	4160	6025	2450	6401	2097	2219
F-250	05-07	Over 8500 GVWR / 4x2 with in bed hitch	4160	6025	2400	6781	2097	2219
F-250	99-04	Over 8500 GCWR (4x2 / 4x4 / with in bed hitch)			2330	6401	2097	2219
F-250	97-08	Over 8500 GVWR / 4x4 / LIFTED			2264*	6401	2097	2219
F-350	06-08		4101	6002	2071 *	6781	2097	2219
F-350	06-08		4160	6025	2071 *	6781	2097	2219
F-350	05		4160	6025	2071 *	6781	2097	2219
F-350	70-04		4101	6002	2071 *	6781	2097	2219
F-350	63-69				2071 *	6781	2097	2219
F-350	84-04	4x2,4x4	2223	6762	2071 *	6781	2097	2219
F-350	63-83	4x2			2071 *	6781	2097	2219
F-350	08	4x2 only with in bed hitch	4101	6002	2450	6401	2097	2219
F-350	06-07	4x2	4101	6002	2398	6401	2097	2219
F-350	05	4x4	4160	6025	2398	6401	2097	2219
F-350	08	4x4 only with in bed hitch	4160	6025	2450	6401	2097	2219
F-350	05-07	4x4	4160	6025	2400	6401	2097	2219
F-350	99-04	(4x2 only) with in bed hitch			2330	6401	2097	2219
F-350	63-08	LIFTED 4" WITH SPRINGS (4X2, 4x4)			2264 *	6781	2097	2219
F-450	08	4x2 only	4101	6002	2442	7325	2097	2219
F-450	08	4x4 only	4160	6025	2442	7325	2097	2219
F-450	08	(4x2, 4x4 ) with in bed hitch			2446	7701	2097	2219
<b>Ford Commercial Vehicles - Europe</b>								
Transit 100/120	89-99	Suitable for Transit Square Axle without Anti Roll Bar			2123	0335	2236	2436
Transit 130/160/190	89-99	Suitable for Transit Round Axle without Anti Roll Bar			3001	0335	2236	2436
Transit LSV 100/120/130/160/190	89-99	Suitable For All Models 100/120/130/160/190			3000	9019	2236	2436
Transit	00-03	Suitable for Transit Square Axle Single Rear Wheel - ABS Vehicles only			3450	6781	2236	2436
Transit	00-03	Suitable for Transit Round Axle Single Rear Wheel - ABS Vehicles only			3451	6781	2236	2436
Transit	00-08	Suitable for Transit Round Axle Dual Rear Wheel - ABS Vehicles only			3448	6781	2236	2436
Transit	04-08	Front Wheel Drive / Square Rear Axle (Type 330-350)-ABS Vehicles Only			3446	6397	2236	2436
Transit	04-08	Front Wheel Drive / Square Rear Axle (Type 260-300)-ABS Vehicles Only			3449	6397	2236	2436
Transit FT350	04-08	Rear Wheel Drive / Round Rear Axle-ABS Vehicles Only			3447	6397	2236	2436
E-250	07-08		4101	6002	2061	6784	2097	2168
E-350	92-08	Dual rear wheels, Box van. Type III Ambulance	4101	6002	2061	6764	2097	2168
E-350	75-91		4101	6002	2032	0335	2097	2168
E-450	08		4101	6002	2458	6397	2097	2168
E-450	96-07	Requires 2' clearance above frame	4101	6000	2377	6397	2097	2168
E-450	96-07	Requires 2' clearance above frame	4101	6000	2153+	6781	2097	2168
E-550	02-03				2300	6873	2097	2168
F-350	05-08	4x2			2176*	6781	2097	2168
F-350	99-04	4x2	4101	6002	2176*	6781	2097	2168
F-350	99-04	4x4	2223	6959	2176*	6781	2097	2168
F-350	80-97	Type I Ambulance Chassis			2065***	0335	2097	2168
F-450	05-08	4x2 / 4x4			2176*	6781	2097	2168
F-450	99-04	4x2 / 4x4	2189	6959	2176*	6781	2097	2168
F-550	05-08	4x2 / 4x4	4160	6025	2404*	6781	2097	2168
F-550	99-04	4x2 / 4x4	2189	6959	2176*	6781	2097	2168
F-650	02-08		2363	6781			2097	2168
LCF-45, LCF-55	06-08	With side fuel tanks for rear kit (Rear kit does not fit 115" wb)	2438	6397	2437	5405	2097	2168
<b>Ford Motorhomes Class 'C' Vans</b>								
E-350 (w/ dual rear wheels)	92-08		4101	6002	2061	6764	2097	2168
E-350 (may require tailpipe modification)	75-91		4101	6002	2032	0335	2097	2168
E-450	08		4101	6002	2458	6397	2097	2168
E-450	96-07		4101	6000	2377	6397	2097	2168
E-450 (requires 2" clearance above frame)	96-08		4101	6000	2153 +	6781	2097	2168
E-550	02-03				2300 ***	6873	2097	2168
<b>Ford Class 'A' Motorhomes</b>								
E33	92-96	With front coil springs	4101	6002	2061	6764	2097	2168
E33	86-91	With front coil springs	4101	6002	2032	0335	2097	2168
F53	99-08	15,000, 18,000, 20,500 & 22,000GVW	2070	0335	2170+	6781	2097	2168
F53	90-98	15,000, 16,000 & 17,000 GVW	2070	0335	2068+	0335	2097	2168

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS		
							SINGLE	DUAL	
<b>Freightliner Vans &amp; Mini Motorhomes (Mercedes)</b>									
Sprinter 2500	02-04					2312+++	9002	2097	2219
Sprinter3500	02-04	(Cab & Chassis)				2382	6397	2097	2219
Sprinter3500	03-04	(Van & Cab & Chassis)				2425	6781	2097	2219
<b>Freightliner / Oshkosh / John Deere Class 'A' Motorhomes</b>									
'M' and 'X' Chassis	94-98	(not XC21) below 22,000 GVW	2124	0335	2071*		6781	2097	2219
'M' and 'X' Chassis	87-93	(not XC21) below 22,000 GVW	1170	0335	2024		1132	2097	2219
<b>Honda Vans</b>									
Odyssey	99-08					4138	6017	2236	2436
Odyssey	96-98					4133	6018	2236	2436
<b>Honda SUVs</b>									
Passport	98-02	4x2 / 4x4				4136	6014	2236	2436
Pilot	01-06					4138	6017	2236	2436
<b>Hummer</b>									
H2, H2 SUT (With Rear Coil Springs)	03-08	4x4				4108	6003	2236	2436
<b>Hyundai Van</b>									
Veracruz	07-08	Coil Rite Kit				4170	6017	2236	2436
<b>Hyundai SUVs</b>									
Santa-Fe	01-06	Coil Rite Kit				4167	6027	2236	2436
Santa-Fe	07-08	Coil Rite Kit				4170	6017	2236	2436
Terracan	01-07	Coil Rite Kit				4124	6007	2236	2436
<b>Infinity SUVs</b>									
FX35, FX45	03-08	4x2 / 4x4				4118	6018	2236	2436
QX 56	05-06					4150	6023	2236	2436
<b>Isuzu Vans</b>									
Oasis	96-98					4133	6018	2236	2436
<b>Isuzu SUVs</b>									
Amigo	98-00					4103	6014	2236	2436
Axiom	02-03					4136	6014	2236	2436
Rodeo, Rodeo Sport	98-04	With rear coil springs				4136	6014	2236	2436
Trooper	98-02	4x4 Leaf Spring vehicle with ABS				3460	6781	2236	2436
Trooper	98-04	Coil Sprung				4143	6016	2236	2436
Trooper	92-97	Coil Sprung				4106	6015	2236	2436
D-MAX / Rodeo	03-08	4x4 Leaf Spring vehicle with ABS				3460	6781	2236	2436
<b>Isuzu Trucks</b>									
Isuzu 290i, 370i	06-08					2384	6397	2236	2436
<b>Isuzu Commercial Vehicles (vehicles without factory bed)</b>									
NPR	96-08		2440	6868				2236	2436
<b>Iveco</b>									
Daily 35-10, 35-12, 45-10, 45-12	90-99	Light Duty Applications				2089	6781	2236	2436
Daily 35-10, 35-12, 45-10, 45-12	90-99	LSV Kit For Non-ABS Vehicles				3082	3000	2236	2436
Daily 35-10 to 49-12,	90-99	For All Applications-Twin Rear Wheel (With ABS) - 4 Bag System				3455	9000	2236	2436
Daily 35C-11 to 35C-13,	00-06	Twin Rear Wheel (With ABS) - 4 Bag System				3456	9000	2236	2436
Daily 35C to 50C	06-08	Twin Rear Wheel (With ABS)				3410	0335	2236	2436
Daily 40C-13, 50C-13,	00-06	Twin Rear Wheel (With ABS) - 4 Bag System				3456	9000	2236	2436
Daily 35 S-L 11 To 17	00-06	Single rear wheel (Leaf Below Axle)				3438	6784	2236	2436
Daily 29-35 S-L 11 To 18	00-08	Single rear wheel (Leaf Above Axle)				3439	6397	2236	2436
<b>Jeep SUVs</b>									
Commander	06-08	4x2 / 4x4				4157	6005	2236	2436
Grand Cherokee	05-08	4x2 / 4x4				4157	6005	2236	2436
Grand Cherokee	92-98	4x2 / 4x4				4118	6018	2236	2436
Grand Wagoneer	92-98	4x2 / 4x4				4118	6018	2236	2436
Liberty	02-08	4x2 / 4x4				4146	6005	2236	2436
Summit	92-93	Coil Rite Kit				4105	6013	2236	2436
Wrangler X	07-08	4x2 / 4x4				4173	6006	2236	2436
Wrangler Sahara	07-08	4x2 / 4x4				4173	6006	2236	2436
Wrangler Rubicon	07-08	4x4 Only				4172	6007	2236	2436
Wrangler Unlimited X	07-08	4x2 / 4x4				4173	6006	2236	2436
Wrangler Unlimited Sahara	07-08	4x2 / 4x4				4173	6006	2236	2436
Wrangler Unlimited Rubicon	07-08	4x4 Only				4172	6007	2236	2436
Wrangler	07-08	4x2 / 4x4				4157	6005	2236	2436

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS		
							SINGLE	DUAL	
<b>Kia Vans</b>									
Sonoda	06-08					4138	6017	2236	2436
<b>Kia SUVs</b>									
Sorento	03-08					4153	6024	2236	2436
<b>Land Rover SUVs</b>									
Defender 90	90-97					4121	6003	2236	2436
Defender 110	83-08					4510	6010	2236	2436
Discovery Series 1&2	90-04	With rear coil springs				4121	6003	2236	2436
Range Rover	90-96	With rear coil springs				4121	6003	2236	2436
Range Rover 93MY, HSE 97MY	95-08	OEM-Original Landrover Suspension-Replacement Bags	OEM	0200	OEM	0027	---	---	---
<b>Lexus SUVs</b>									
LX 450	96-98					4124	6007	2236	2436
LX 470	99-08					4124	6007	2236	2436
<b>Lincoln Cars</b>									
Continental	82-88	With rear coil springs				4106	6015	2236	2436
Mark IV	84-87	With rear coil springs				4106	6015	2236	2436
Towncar	80-89					4108	6003	2236	2436
<b>Lincoln CUV</b>									
MKX	07-08					4171	6020	2236	2436
<b>Lincoln Truck</b>									
LT	05-08	4x2 / 4x4				2350	6397	2236	2436
<b>Mazda Cars</b>									
626	79-82					4591	6591	2236	2436
Mazda5	06-08					4168	6027	2236	2436
Mazda6	06-08					4168	6027	2236	2436
<b>Mazda Vans</b>									
MPV	06-08					4140	6018	2236	2436
MPV Van	96-98					4105	6013	2236	2436
<b>Mazda Pickup Trucks</b>									
B2500/ BT-50	00-08	4x4-For Vehicles Fitted with ABS				3454	6781	2236	2436
Pickup	72-90	4x2				1130**	0335	2236	2436
<b>Mercedes Vans and Commercial Vehicles</b>									
Vito	96-03	Front Wheel Drive Vehicle				4145	6028	2236	2436
Vito	03-08	Rear Wheel Drive Vehicle				4261	6016	2236	2436
Vito	03-08	Full Air Kit-Rear Axle Kit only c/w shock absorbers				3489	9041	---	---
Vito	03-08	Full Air Kit-Electronic Height Control-With Lowering				3487	9041	---	---
3 Series Sprinter - 207 - 310	88-96	For All Applications				3004	6781	2236	2436
3 Series Sprinter - 308, 310, 312, 313, 316	96-06	Chassis Cab / Motorhome Application				3114	9000	2236	2436
3 Series Sprinter - 308, 310, 312, 313, 316	96-06	All Applications				2312	9002	2236	2436
Sprinter 209, 211, 213, 215	06-08	ABS Vehicles Only				3500	6397	2236	2436
Sprinter 309, 311, 313, 315, 318, 324	06-08	ABS Vehicles Only				3500	6397	2236	2436
4 Series Sprinter - 408, 410, 412, 413, 416	96-06	Chassis Cab Version (using 70mm sleeve airsprings)				3119	7095	2236	2436
4 Series Sprinter - 408, 410, 412, 413, 416	96-06	Chassis Cab Version (using double convolute airsprings)				2382	6397	2236	2436
4 Series Sprinter - 408, 410, 412, 413, 416	96-06	Van Version (using 70mm sleeve airsprings)				3461	7095	2236	2436
4 Series Sprinter - 408, 410, 412, 413, 416	96-06	Van Version (using double convolute airsprings)				2425	6397	2236	2436
Sprinter 509, 511, 515, 518, 524	06-08	ABS Vehicles Only				3501	0335	2236	2436
Sprinter 509, 511, 515, 518, 524	06-08	Larger Airsprings For Extra Volume and Comfort (ABS Vehicles Only)				4000	7339	2236	2436
6 Series Sprinter - 616	96-08	4 Bag System				3466	6781	2236	2436
<b>Mercury Cars</b>									
Capri	79-86					4103	6014	2236	2436
Colony Park	83-97	Including station wagons				4108	6003	2236	2436
Cougar	92-97					4105	6013	2236	2436
Cougar	89-91					4104	6012	2236	2436
Cougar	80-88					4106	6015	2236	2436
Grand Marquis	98-08					4107	6021	2236	2436
Grand Marquis	83-97	Including station wagons				4107	6003	2236	2436
Marquis	83-86					4103	6014	2236	2436
Milan	06-08					4168	6027	2236	2436
Sable Station Wagon	99-06					4141	6005	2236	2436
Sable Station Wagon	86-98					4105	6013	2236	2436
<b>Mercury Vans</b>									
Monterey	04-07					4151	6016	2236	2436

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS	
							SINGLE	DUAL
<b>Mitsubishi SUVs</b>								
Expo	92-93	(4x2, 4x4)				4105	6013	2236 2436
Montero Sport	99-04	(4x2, 4x4)				4137	6007	2236 2436
Pajero / Shogun	93-03					4113	6007	2236 2436
Pajero	04-08					4247	6014	2236 2436
L200	90-05	4x4-Fitted with ABS				3457	6781	2236 2436
L200 / Triton / Warrior	06-08	4x4-Fitted with ABS				3469	6781	2236 2436
<b>Mitsubishi Pickup Trucks</b>								
Raider Club Cab	06-08	4x2 / 4x4				2378+++	9000	2236 2436
Raider Quad Cab	06-08	4x2 / 4x4				2379+++	9000	2236 2436
Pickup	69-96	4x2				1130**	0335	2236 2436
<b>Nissan Vans</b>								
Quest	04-08					4118	6018	2236 2436
<b>Nissan SUVs</b>								
Armada	06-08	4x2 / 4x4				4150	6023	2236 2436
Murano	03-08	4x2 / 4x4				4118	6018	2236 2436
Pathfinder Armada	04-05	4x2 / 4x4				4150	6023	2236 2436
Pathfinder	87-95	4x2 / 4x4				4106	6015	2236 2436
Pathfinder	06-08	4x2 / 4x4				4166	6021	2236 2436
Xterra	05-08	4x2/ 4x4				2409	9002	2236 2436
Terrano	92-04	For Use with Original Coil				4106	6015	2236 2436
Patrol	88-94	Leaf Spring 4x2				1130	0335	2236 2436
Patrol	93-08	Coil Spring				4570	6010	2236 2436
D21, D22, Navara	98-04	4x4-Fitted with ABS				3458	0335	2236 2436
D40, Navara	05-08	4x4-Fitted with ABS				2413	6397	2236 2436
<b>Nissan Pickup Trucks</b>								
Frontier	01-04	4x2				2293	9002	2236 2436
Frontier	05-08	4x2, 4x4				2403	6766	2236 2436
Pickup	69-96	4x2				1130**	0335	2236 2436
Titan	04-08	4x4, 4x4				2355	6781	2236 2436
<b>Nissan Vans and Commercial Vehicles</b>								
Primastar X83	01-08	For Use with Original Coil				4250	6021	2236 2436
Primastar X83	01-08	Full Air Kit-Rear Axle Kit only c/w shock absorbers				3465	9041	--- ---
Primastar X83	01-08	Full Air Kit-Electronic Height Control-No Lowering				3244	9041	--- ---
Primastar X83	01-08	Full Air Kit-Electronic Height Control-With Lowering				3166	9041	--- ---
Primastar X83	01-08	LSV				3334	---	--- ---
Interstar X70	98-08	Semi Air Heavy Duty Kit	4117	6004	3123	6784	2236 2436	
Interstar X70	98-08	Complete with Automatic Height Control	4117	6004	3121	9000	2236 2436	
Interstar X70	98-08	Rear Axle Only	4117	6004	3126	9000	2236 2436	
Interstar X70	98-08	LSV			3148	---	--- ---	
Interstar X70	98-08	Full Air Kit-Front Axle	3382	2119	---	---	--- ---	
Atleon LP2 35.15-35HD.15-56.15	06-08				3406	6784	2236 2436	
Atleon LG1 70.14-80.14-80.19	06-08	Auto Levelling kit			3371	6183	--- ---	
Atleon LG1 70.14-80.14-80.19	06-08	Manual Inflation kit			3372	6183	--- ---	
Atleon LG1 70.14-80.14-80.19	06-08	Compressor and Dual Gauge Kit			3373	6183	--- ---	
Atleon LG1 70.14-80.14-80.19	06-08	Compressor and Single Gauge Kit			3374	6183	--- ---	
Cabstar	06-08				3127	6784	2236 2436	
Trade	03-06				3474	0335	2236 2436	
<b>Oldsmobile Cars</b>								
88	85	(RWD)				4116	6010	2236 2436
98	65-84	No station wagons / rear wheel drive				4116	6010	2236 2436
Achieva	92-98					4104	6012	2236 2436
Aurora	95-04					4105	6013	2236 2436
Calais	73-87	No station wagons				4114	6008	2236 2436
Custom Cruiser Station Wagon	77-93					4116	6010	2236 2436
Calais, Cutlass, Cutlass Supreme	73-87	No station wagons				4114	6008	2236 2436
Custom Cruiser	77-93	(SW only)				4116	6010	2236 2436
Cutlass Calais	85-91	(FWD)				4104	6012	2236 2436
Cutlass Cierra	82-96					4103	6014	2236 2436
Cutlass Cruiser	84-95	(SW only) (FWD)				4103	6014	2236 2436
Cutlass, F-85, 442	67-72	(not SW)				4113	6007	2236 2436
Delta 88	64-84	(not SW) (RWD)				4116	6010	2236 2436
Delta 88, 98 (FWD)	85-99	Front wheel drive				4107	6021	2236 2436

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS		
							SINGLE	DUAL	
<b>Oldsmobile Cars (Cont)</b>									
Firenza	82-88	(FWD)				4104	6012	2236	2436
LSS	96-01					4107	6021	2236	2436
Toronado	79-85					4106	6015	2236	2436
<b>Oldsmobile Vans</b>									
Silhouette	90-96					4110	6014	2236	2436
<b>Oldsmobile SUVs</b>									
Bravada	02-05	(4x2, 4x4) (with rear coil springs)				4106	6015	2236	2436
Bravada	91-94	(4x4 only)				2022	0335	2236	2436
<b>Opel Pickup, Vans and Commercial Vehicles</b>									
Campo	88-08	4x4 Campo - Fitted with ABS				3460	6781	2236	2436
Vivaro X83	01-08	For Use with Original Coil				4250	6021	2236	2436
Vivaro X83	01-08	Full Air Kit-Rear Axle Kit only c/w shock absorbers				3465	9041	---	---
Vivaro X83	01-08	Full Air Kit-Electronic Height Control-No Lowering				3244	9041	---	---
Vivaro X83	01-08	Full Air Kit-Electronic Height Control-With Lowering				3166	9041	---	---
Vivaro X83	01-08	LSV				3334	---	---	---
Movano X70	98-08	Semi Air Heavy Duty Kit	4117	6004	3123	6784	2236	2436	
Movano X70	98-08	Complete with Automatic Height Control	4117	6004	3121	9000	2236	2436	
Movano X70	98-08	Rear Axle Only	4117	6004	3126	9000	2236	2436	
Movano X70	98-08	LSV			3148	---	---	---	
Movano X70	98-08	Full Air Kit-Front Axle	3382	2119	---	---	---	---	
<b>Peugeot</b>									
307	04-08	For Use with Original Coil				4158	6262	2236	2436
Expert	96-06	For Use with Original Coil				4143	6016	2236	2436
Expert-G9	07-08	For Use with Original Coil				4264	6016	2236	2436
Expert-G9	07-08	Full Air Kit-Electronic Height Control-With Lowering				3496	9931	---	---
J5 - Euro Chassis 280/290	88-93	For All Applications				2112	6781	2236	2436
J5 - Euro Chassis 280/290	88-93	LSV Kit For Non-ABS Vehicles				3003	3000	2236	2436
J5 - Euro Chassis 280/290	88-93	LSV Linkage For Non-ABS Vehicles (Motorhomes)				3149	Link	2236	2436
BOXER - Euro Chassis X230	94-01	Commercial Vehicle Application				2110	6781	2236	2436
BOXER - Euro Chassis X230	94-01	LSV Kit For Non-ABS Vehicles				3003	3000	2236	2436
BOXER - Euro Chassis X230	94-01	LSV Linkage For Non-ABS Vehicles (Motorhomes)				3149	Link	2236	2436
BOXER - Euro Chassis X244	02-06	Commercial Vehicle Application				2110	6781	2236	2436
BOXER - Euro Chassis X244	02-06	LSV Kit For Non-ABS Vehicles				3178	Cylinder	2236	2436
BOXER - Euro Chassis X250	06-08	All Applications				2428	6781	2236	2436
BOXER - Euro Chassis X250	06-08	Larger Airsprings For Extra Volume and Comfort				2429	7339	2236	2436
BOXER - Euro Chassis X250	06-08	Full Air Improvement Comfort Kit				3202	9934	---	---
<b>Plymouth Cars</b>									
Acclaim	89-95					4105	6013	2236	2436
Caravelle	85-88					4105	6013	2236	2436
Reliant	81-94					4105	6013	2236	2436
Sundance	87-93					4105	6013	2236	2436
<b>Plymouth Trucks</b>									
Arrow	80-93					1130**	0335	2236	2436
<b>Pontiac Cars</b>									
6000	82-91					4103	6014	2236	2436
Bonneville	00-05					4105	6013	2236	2436
Bonneville	87-99	Front wheel drive				4107	6021	2236	2436
Firebird, Trans Am	82-02					4103	6014	2236	2436
Grand Am	85-97					4104	6012	2236	2436
Grand Am, Le Mans, Grand Le Mans	73-82	Including station wagons				4114	6008	2236	2436
Grand Prix	73-87					4114	6008	2236	2436
Grand Prix	68-72					4113	6007	2236	2436
Grand Prix	65-68					4114	6008	2236	2436
Grandville	71-73					4116	6010	2236	2436
J-2000	82-94	Including station wagons				4104	6012	2236	2436
Le Mans	88-92					4104	6012	2236	2436
Le Mans, Custom, 'S', Judge, Tempest, GTO, GT37	68-72	No station wagons				4113	6007	2236	2436
Phoenix	80-84					4103	6014	2236	2436
Safari Station Wagon	77-89					4116	6010	2236	2436
<b>Pontiac Vans</b>									
Transport APV	90-96					4110	6014	2236	2436
<b>Pontiac SUV</b>									
Torrent	05-07	(4x2, 4x4)				4167	6027	2236	2436

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS		
							SINGLE	DUAL	
<b>Renault</b>									
Espace	00-02	For Use with Original Coil				4251	6017	2236	2436
Espace	03-08	For Use with Original Coil				4250	6021	2236	2436
Espace	01-08	Full Air Kit-Rear Axle Kit only c/w shock absorbers				3172	9931	---	---
Espace	01-08	Full Air Kit-Electronic Height Control-With Lowering				3490	9931	---	---
Kangoo X61	2008	Full Air Kit-Electronic Height Control-With Lowering				3167	9000	---	---
Laguna II	02-03	For Use with Original Coil				4106	6015	2236	2436
Trafic X83	01-08	For Use with Original Coil				4250	6021	2236	2436
Trafic X83	01-08	LSV				3334	---	---	---
Trafic X83	01-08	Full Air Kit-Rear Axle Kit only c/w shock absorbers				3465	9041	---	---
Trafic X83	01-08	Full Air Kit-Electronic Height Control-No Lowering				3244	9041	---	---
Trafic X83	01-08	Full Air Kit-Electronic Height Control-With Lowering				3166	9041	---	---
Mascot	05-08					3125	6784	2236	2436
Master X70	98-08	Semi Air Heavy Duty Kit	4117	6004	3123	6784	2236	2436	
Master X70	98-08	Complete with Automatic Height Control	4117	6004	3121	9000	---	---	
Master X70	98-08	Rear Axle Only	4117	6004	3126	9000	2236	2436	
Master X70	98-08	LSV				3148	---	---	---
Master X70	98-08	Full Air Kit-Front Axle	3382	2119		---	---	---	---
Master X70	98-03	Full Air Improvement Comfort Kit	4117	6004	3141	9931	---	---	
Maxity	06-08					3127	6784	2236	2436
<b>Saturn Van</b>									
Relay	05-07					4155	6020	2236	2436
<b>Saturn SUVs</b>									
Vue	02-07					4167	6027	2236	2436
<b>Scion Cars</b>									
Xa	04-07					4136	6014	2236	2436
xD	08					4136	6014	2236	2436
<b>Spartan Class 'A' Motorhomes</b>									
EC2000	91-96	Round axle only	2102	6762	2074	2107	2097	2168	
<b>Ssangyong SUVs</b>									
Rexton/Actyon	02-08	For Use with Original Coil				4103	6014	2236	2436
Musso Sport	04-06	For Use with Original Coil				4240	6015	2236	2436
Musso Wagon	92-06	For Use with Original Coil				4241	6024	2236	2436
<b>Sterling Commercial Vehicles (vehicles without factory bed)</b>									
Bullet	08	(4x2, 4x4) (Cab & Chassis)				2153+	6781	2097	2168
<b>Suzuki</b>									
Vitara	90-00	For Use with Original Coil				4620	3624	2236	2436
Jimny	06-08	For Use with Original Coil	4515	4515	4516	4516	2236	2436	
Sidekick	89-93	For Use with Original Coil				4620	3624	2236	2436
<b>Toyota Cars</b>									
Echo	01-05					4118	6018	2236	2436
Yaris	07-08					4136	6014	2236	2436
<b>Toyota Vans</b>									
Siena	04-08					4155	6020	2236	2436
Siena	98-03					4118	6018	2236	2436
Van	64-89	(with rear coil springs)				4112	6006	2236	2436
<b>Toyota Vans, SUVs and Pickups</b>									
RAV4	07-08					4174	6028	2236	2436
RAV4	96-98					4104	6012	2236	2436
Dyna 150	02-08	Dual Rear Wheel Only				3128	0335	2236	2436
FJ Cruiser	07-08					4135	6024	2236	2436
4-Runner	90-95					4112	6006	2236	2436
4-Runner	96-97					4123	6021	2236	2436
4-Runner	98-08					4135	6024	2236	2436
Sequoia	01-07	4x2 / 4x4				4124	6007	2236	2436
Landcruiser	91-08	Coil Spring Vehicle				4124	6007	2236	2436
Landcruiser	88-96	Leaf Spring Vehicle - BJ75 Pick-up				1130	0335	2236	2436
Landcruiser (100 Series)	98-07					4114	6008	2236	2436
Landcruiser (200 Series)	07-08					4129	6010	2236	2436
Hiace	99-02	With Rear Coil Springs				4500	3600	2236	2436
Hiace	03-08	With Rear Coil Springs				4138	6017	2236	2436
Hilux	88-05	4 x 4 N16 / N17 - vehicles fitted with ABS				3459	6781	2236	2436
Hilux / Vigo	06-08	4 x 4 Vehicles fitted with ABS				3475	0335	2236	2436
Hilux / Vigo	06-08	LSV				3452	---	---	---

MAKE / MODEL	YEAR	NOTES	FRONT KIT	AIR APRING	REAR KIT	AIR SPRING	AIR ACCESSORY SYSTEMS		
							SINGLE	DUAL	
<b>Toyota Pickup Trucks</b>									
Pickup	69-95	4x2 Only				1130**	0335	2236	2436
Pickup	84-95	4x4 Only				2116	6781	2236	2436
T 100	93-98	4x2 Only				2115	6781	2236	2436
T 100	93-98	4x4 Only				2116	6781	2236	2436
Tacoma	05-08	4x2 Only				2410	6762	2236	2436
Tacoma	95-04	4x2 Only				2213	6762	2236	2436
Tacoma Prerunner	05-08	4x2 Only				2407	6397	2236	2436
Tacoma Prerunner	95-04	4x2 Only				2304	6781	2236	2436
Tacoma	05-08	4x4 Only				2407	6397	2236	2436
Tacoma	95-04	4x4 Only				2304	6781	2236	2436
Tundra	07-08	4x2 , 4x4				2445	6397	2236	2436
Tundra	00-06	4x2 Only				2212	9001	2236	2436
Tundra TRD	00-06	4x4 , 4x2				2245	6781	2236	2436
Tundra	00-06	4x4 Only				2245	6781	2236	2436
<b>Vauxhall Vans and Commercial Vehicles</b>									
Vivaro X83	01-08	For Use with Original Coil				4250	6021	2236	2436
Vivaro X83	01-08	Full Air Kit-Rear Axle Kit only c/w shock absorbers				3465	9041	---	---
Vivaro X83	01-08	Full Air Kit-Electronic Height Control-No Lowering				3244	9041	---	---
Vivaro X83	01-08	Full Air Kit-Electronic Height Control-With Lowering				3166	9041	---	---
Vivaro X83	01-08	LSV				3334	---	---	---
Movano X70	98-08	Semi Air Heavy Duty Kit	4117	6004	3123	6784	2236	2436	
Movano X70	98-08	Complete with Automatic Height Control	4117	6004	3121	9000			
Movano X70	98-08	Rear Axle Only	4117	6004	3126	9000	2236	2436	
Movano X70	98-08	LSV			3148	---	---	---	
Movano X70	98-08	Full Air Kit-Front Axle	3382	2119	---	---	---	---	
<b>Volkswagen Cars</b>									
Eos, GTI	07-08	Coil Rite Kit				4176	6027	2236	2436
Passat Wagon, Jetta	07-08	Coil Rite Kit				4175	6026	2236	2436
Passat	98-06	N16 / N17 - For Vehicles fitted with ABS				4104	6003	2236	2436
<b>Volkswagen Vans and Commercial Vehicles</b>									
Caddy Pickup (Skoda)	98-08	Coil Rite Kit				4144	6026	2236	2436
Taro (4x4)	88-04	N16 / N17 - For Vehicles fitted with ABS				3459	6781	2236	2436
Euro Van, T-4	85-03	Coil Rite Kit				4117	6004	2236	2436
Euro Van, T-4	85-03	Full Air Kit - Rear Axle Kit only				3022	6988	2236	2436
T5 Van / Bus	04-08	Full Air Kit - Rear Axle Kit only				3482	6988	2236	2436
T5 Van / Bus	04-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers				3498	6988	2236	2436
T5 Van / Bus	04-08	Full Air Kit - Electronic Height Control - With Lowering				3483	6988	2236	2436
T5 Chassis Cab	04-08	Full Air Kit - Rear Axle Kit only				3481	6988	2236	2436
T5 Chassis Cab	04-08	Full Air Kit - Rear Axle Kit only c/w shock absorbers				3499	6988	2236	2436
T5 Chassis Cab	04-08	Full Air Kit - Electronic Height Control - With Lowering				3484	6988	2236	2436
T5 Van / Bus	04-08	Full Air Kit - Front Axle - 2.8 Tonne Vehicle - 1540 Kg Front Axle Load	5506					2236	2436
T5 Van / Bus / Chassis	04-08	Full Air Kit - Front Axle - 3.2 Tonne Vehicle - 1710 Kg Front Axle Load	5507					2236	2436
3 Series LT	96-06	Chassis Cab / Motorhome Application				3114	9000	2236	2436
3 Series LT	96-06	All Applications				2312	9002	2236	2436
Crafter 28 - 35	06-08	ABS Vehicles Only				3500	6397	2236	2436
4 Series LT	96-06	Chassis Cab Version (using 70mm sleeve airsprings)				3119	7095	2236	2436
4 Series LT	96-06	Chassis Cab Version (using double convolute airsprings)				2382	6397	2236	2436
4 Series LT	96-06	Van Version (using 70mm sleeve airsprings)				3461	7095	2236	2436
4 Series LT	96-06	Van Version (using double convolute airsprings)				2425	6397	2236	2436
Crafter 50	06-08	ABS Vehicles Only				3501	0335	2236	2436
Crafter 50	06-08	Larger Airsprings For Extra Volume and Comfort (ABS Vehicles Only)				4000	7339	2236	2436
<b>Volvo</b>									
140,160	66-74	Coil Rite Kit				4101	6002	2236	2436
240,260	75-85	Coil Rite Kit				4106	6015	2236	2436
850	90-01	Coil Rite Kit				4105	6013	2236	2436
<b>Workhorse Class "A" Motorhomes</b>									
P30, P32	00-07	10,500 to 17,000 GVW				2147*	6781	2097	2168
P30, P32	00-07	10,500 to 16,000,17,000 GVW				2085	0335	2097	2168
P30, P32	00-07	18,000 GVW				2218*	6781	2097	2168
W22, W20	02-03	Up to production date 10/27/03	2284	6781	2287	5405	2097	2168	
W22, W20, W24	04-08		2284	6781	2347	5405	2097	2168	
UFO	07-08				2457	7689	2097	2168	

## Notes

**DO NOT EXCEED THE VEHICLE'S RECOMMENDED GROSS VEHICLE WEIGHT RATING (GVWR)**

\*\*\*\*Please confirm exact model type and full specification when ordering to ensure correct kit supply

Minimum Tyre to Frame clearance requirements \*=7.50" \*\*=3.00" \*\*\*=9.50" +=8.00" ++=6.00" +++=6.50"

Air Pressure Requirements			
<b>Semi-Air</b>			
Minimum	10 P.S.I.	Maximum	100 P.S.I.
<b>Coil-Rite</b>			
Minimum	5 P.S.I.	Maximum	20-35 P.S.I.

**DriveRite**  
**Unit 626, Kilshane Avenue**  
**North West Business Park**  
**Ballycoolin**  
**Dublin 15**  
**Ireland**  
**Tel: +353 1 8612 632**  
**Fax: +353 1 8612 647**  
**email: sales@driveriteltd.com**