



Unit 626 Kilshane Avenue, North West Business Park, Ballycoolin, Dublin 15, Ireland
 Telephone: +353 1 8612 632, Fax: +353 1 8612 647, email: sales@driveriteltd.com

W21-760-2430

INSTALLATION INSTRUCTIONS

All work should be carried out in a properly equipped workshop with due regard to Health and Safety Regulations. No further reference to Health and Safety Regulations will be made, but they must be considered at all times.

The kit should be opened and the contents checked against the parts list provided.

Identify the various components and familiarise yourself with them using drawings and information provided.

WARNING

Do not inflate this assembly when it is unrestricted. When installed, a minimum of 10 psi should be maintained in the air bellows at all times to avoid damage. Do not inflate beyond 100 psi.

IMPORTANT

This kit is not designed to increase the GVW of your vehicle. For your safety and to prevent possible damage to your vehicle, do not exceed the maximum load recommended by the vehicle manufacturer.

AIR SPRING	6397	2	5/16" -18 FLANGED LOCK NUT	8
UPPER BRACKET	5528	2	5/16" FLAT WASHER	4
LOWER BRACKET	5529	2	18 ft. TUBING	0938 1
SPACER	5224	2	INFLATION VALVE	3032 2
10MM X 50MM FLAT HEAD BOLT		2	MALE FITTING	3055 2
3/8" -16 X 3/4" FLANGED HEX BOLT		2	THERMAL SLEEVE	0899 2
J-BOLT		8	NYLON TIES	6
5/8" -18 JAM NUT		2	CAUTION TAG	2



